## **BIG BUTTON REMOTE CONTROL FOR AMINO & CISCO SET TOP BOXES**

Used in all XIT markets.

This remote is powered by 2 AAA batteries and features a glow-in-the-dark numeric keypad.

### To Program Amino A140 & A540 Set Top Boxes:

Press & hold the CBL Button and OK/SEL Button for three (3) seconds at the same time.

The CBL Button will then light up and stay lit.

Point the remote at the set top box and enter 236 on the keypad (this is the code for the Amino set top boxes)

Press CBL Button again to lock in the settings – LED blinks twice to confirm the code is stored. The set top box will then shut off.

Press CBL Button again to turn the set top box back on.

# To Program Cisco 330/430 Set Top Boxes:

The instructions are the same as above with the exception that the code for the Cisco set top boxes is 156.

### To Program The Remote to TV for Power & Volume:

Press & hold the TV Button and the OK/SEL Button for three (3) seconds at the same time.

Press & hold the Channel Up Button until the TV turns off.

Press TV Button again to lock in the settings.

Make sure the buttons work. If not – go back through the steps above.

### **BIG BUTTON REMOTE CONTROL**

